

*Laboratoire de Dynamique et Structure des Matériaux Moléculaires
UMR 8024 – Université de Lille 1-France*

SOLID STATE TRANSFORMATIONS OF PHARMACEUTICAL COMPOUNDS UPON MILLING: LACTOSE & MANNITOL

(authorized version)

**V. Caron, J-F. Willart, R. Lefort, J. Lefebvre,
M.
Descamps**

PPXRD 08, Glasgow, 04-07 May 2009

This document was presented at PPXRD - Pharmaceutical Powder X-ray Diffraction Symposium

Sponsored by The International Centre for Diffraction Data

This presentation is provided by the International Centre for Diffraction Data in cooperation with the authors and presenters of the PPXRD symposia for the express purpose of educating the scientific community.

All copyrights for the presentation are retained by the original authors.

The ICDD has received permission from the authors to post this material on our website and make the material available for viewing. Usage is restricted for the purposes of education and scientific research.





PPXRD Website – www.icdd.com/ppxrd

ICDD Website - www.icdd.com

In the field of
MOLECULAR MATERIALS
(i.e. pharmaceutical compounds) :

NO
SYSTEMATIC
INVESTIGATIONS
(theoretical or experimental)

Milling of pharmaceutical compounds



No systematic investigations

In spite of :


- Importance of applications
- Original aspects of molecular materials
(Fundamental studies)

Molecular compounds specificities

Contrast between :

Weak **inter-molecular** interactions

Strong **intra-molecular** interactions



Low Symmetry
Important size




Molecules
cells (often tricl., mono. or ortho.)

- Low melting temperatures
- **Glass transition temperature close of RT $\cong T_{\text{milling}}$**
Easy
- Low kinetics of cryst \longleftrightarrow Quench-Vitrification
- Very sensitive to mechanical and thermal perturbations

Transfo. on milling of pharmaceutical compounds

Materials selection



Plan of speech

I – Milling

Characteristics of milling experiments realized at the laboratory

II – Stable anhydrous α -lactose

- Solid-state amorphization of αL_S
- Mutarotation (^{13}C NMR)

III – Mannitol


Mannitol δ
Mannitol β } Polymorphic transformations

Characteristics of milling

Pulverisette 7
Fritsch



$N \times \left\{ \begin{array}{l} \text{milling (20min)} \\ \text{pause (10min)} \end{array} \right.$




Prevention of hygroscopy


Lactose – possible solid-state forms

Disaccharid often used in Pharmaceutical and Food industries

2 types of molecules of lactose :



α -lactose




β -lactose

Various solid-state forms:

- Monohydrated α lactose ($L_{\alpha}\text{-H}_2\text{O}$) (stable)
- Hygroscopic anhydrous α lactose
- **Stable anhydrous α lactose (αL_S)**
- Anhydrous β lactose
- Molecular compounds α/β with various stoichiometries


Problems encountered for producing amorphous lactose

Thermal degradations and caramelization




α -lactose

Mutarotation




(in solution...)




β -lactose

Amorphization of α L_S under milling


NMR ^1H liq



PXRD



DSC



Crystalline
 α lactose


milling

Glassy α lactose
without degradations


recrys

Crystalline
 α/β lactose

Solid-state NMR ^{13}C : characterization *in situ* % β




$\text{C}_1 \text{ glu}_{\alpha\text{lactose}} \neq \text{C}_1 \text{ glu}_{\beta\text{lactose}}$
Crystalline or amorphous states





$\text{C}_1 \text{ glu}$

- Detection mutarotation
- Quantification % β *in situ*
- $\% \beta = f(T^\circ\text{C})$

Mutarotation during heating of amorphous α L




Milling amorphization \neq local melting-quench



Glassy αL $\xrightarrow{\hspace{1cm}}$ Out of equilibrium
Mutarotation $\xleftarrow{\hspace{1cm}}$ Structural relaxation below T_g

$T_{\text{mil}} < 85^\circ\text{C} < T_m$
~~Local melting / quench~~


No mutarotation during heating of crystalline αL_S




Mannitol

Characteristics of Mannitol :

- Acyclic polyol present in seafood, fruits, mushrooms...





- Used as excipient, sweetener, API




Adapted from
Burger et al.,
*J. Pharm.
Sciences*,
2000, 89, 457



Polymorphic transformation under milling of M β and M δ



Interpretation of amorphization αL_S under milling as a « Driven system* »



Interpretations polymorphic transformations mannitol under milling as a Driven system



Conclusion

Crystalline
 α lactose $\xrightarrow{\text{milling}}$

Glassy α lactose
without degradations

Glassy
 αL

$\xrightarrow{\text{heating}}$

Mutarotation

Irreversible
at $T < T_g$

~~Local
quench
melting~~

Glassy αL
Out of
equilibrium

Mannitol β

Milling

Mannitol α

Mannitol δ

Aging

$\xrightarrow{\text{Room } T^\circ C}$

Mannitol β

States reached are stationary states rather than thermodynamic equilibrium states

Acknowledgements

- Pr. Marc Descamps
- Dr. Jean-François Willart
- Dr. Ronan Lefort
- Pr. Jacques Lefebvre
- Dr. Patrick Derollez
- Mme. Florence Danede
- M. Dominique Prevost

Publications related to this presentation

- J.F. Willart, V. Caron, R. Lefort, F. Danède, D. Prévost and M. Descamps, "Athermal character of the solid state amorphization of lactose induced by ball milling", *Solid State Communications*, 2004, 132, pp. 693.
- J. Lefebvre, J.F. Willart, V. Caron, R. Lefort, F. Affouard and F. Danede, "Structure determination of the 1/1 α/β mixed lactose by X-ray powder diffraction", *Acta Cryst. B*, 2005, 61, pp. 455.
- R. Lefort, V. Caron, J.F. Willart and M. Descamps, "Mutarotational kinetics and glass transition of lactose", *Solid State Communications*, 2006, 140, pp. 329.
- P. Zhang, N. Klymachyov, S. Brown, J.C. Ellington and P.J. Grandinetti, "Solid state ^{13}C NMR investigations of the glycosidic linkage in a-a' trehalose", *Solid state Nuclear Magnetic Resonance*, 1998, 12, pp 221.

Publications related to this presentation

- R. Lefort, A. De Gusseme, J.F. Willart, F. Danede and M. Descamps, "Solid State NMR and DSC methods for quantifying the amorphous content in solid dosage forms: an application to ball-milling of trehalose", *International Journal of Pharmaceutics*, 2004, 280, pp. 209.
- M. Descamps, J.F. Willart, E. Dudognon and V. Caron, "Transformation of Pharmaceutical Compounds upon milling and comilling : The role of Tg", *Journal of Pharmaceutical Sciences*, 2007, 96, 00, pp. 1-10.
- J. Rodriguez-Carvajal, T. Roisnel, "Fullprof 98 and WinPLOTR: New Windows 95/NT Application for Diffraction", Newsletter 20, 1998.
- H.M. Rietveld, "Line profiles of neutron powder diffraction peaks for structure refinement", *Acta Cryst*, 1967, 22, pp 151.
- H.M. Rietveld, "A profile refinement method for nuclear and magnetic structures", *J. Appl. Cryst.*, 1969, 2, pp 65.